

# BioFlo® 110 Firmware Updates

Date/File/Version	Description of Changes
30-Nov-2006 <b>bfver201.exe</b> Version 2.1	Resolves PCU display issues when switching between different languages. Also improves communication between modules. Use this file only if your BioFlo 110 PCU display is <b>orange and black</b> .

## Instructions

Determine which firmware version is currently installed in the BioFlo 110 Primary Control Unit (PCU):

- Turn on the BioFlo 110 PCU
- Display the Setup Screen by pressing the upper-right touchpad key
- Note the currently installed version number

If the installed version number is lower than the latest version listed above, perform the two-part upgrade. You may want to print this page for easy access to the instructions while you work.

### 1. Create an Upgrade Floppy

- a. Download the latest version, which includes the changes from earlier versions:
  - Click on the latest file name
  - Select "Download to disk"
  - Choose a location on your hard-drive for the download (suggest "desktop")
- b. After the download is complete, create the upgrade floppy:
  - Insert an empty, formatted floppy in your computer
  - Open the downloaded file
  - Follow computer on-screen instructions to create the upgrade floppy

**NOTE:** Contact your IT service for assistance if security software installed at your site prevents downloading or operation of the downloaded file.

### 2. Install The Latest Firmware Version In The Bioflo 110 PCU

- a. Turn OFF the BioFlo 110 PCU
- b. Insert the upgrade floppy into the PCU
- c. Turn ON the PCU
- d. Wait until the "Installation Complete" message appears (about a minute)
- e. Turn off the PCU, remove the disk, and restart.

Congratulations! You have installed the latest performance enhancements in your BioFlo 110. Check this page regularly for new revisions.