

BioFlo® 110 Firmware Updates

Date/File/Version	Description of Changes
30-Nov-2006 bfver201c.exe Version 2.1C	Resolves PCU display issues when switching between different languages. Also improves communication between modules. Use this file only if your BioFlo 110 PCU display is blue and white .

Instructions

Determine which firmware version is currently installed in the BioFlo 110 Primary Control Unit (PCU):

- Turn on the BioFlo 110 PCU
- Display the Setup Screen by pressing the upper-right touchpad key
- Note the currently installed version number

If the installed version number is lower than the latest version listed above, perform the two-part upgrade. You may want to print this page for easy access to the instructions while you work.

1. Create an Upgrade Floppy

- a. Download the latest version, which includes the changes from earlier versions:
 - Click on the latest file name
 - Select "Download to disk"
 - Choose a location on your hard-drive for the download (suggest "desktop")
- b. After the download is complete, create the upgrade floppy:
 - Insert an empty, formatted floppy in your computer
 - Open the downloaded file
 - Follow computer on-screen instructions to create the upgrade floppy

NOTE: Contact your IT service for assistance if security software installed at your site prevents downloading or operation of the downloaded file.

2. Install The Latest Firmware Version In The Bioflo 110 PCU

- a. Turn OFF the BioFlo 110 PCU
- b. Insert the upgrade floppy into the PCU
- c. Turn ON the PCU
- d. Wait until the "Installation Complete" message appears (about a minute)
- e. Turn off the PCU, remove the disk, and restart.

Congratulations! You have installed the latest performance enhancements in your BioFlo 110. Check this page regularly for new revisions.